



RELEASED
W/ 05/07/11

PPP

Part Number	D355-600-143
Description	Spacepod, LH

Box Part Number	MBX115 B/T	Dimension	
Other Packaging	MFSP Kit		
Logo Decals	D3567-1		

Packaging Instructions and Decal Placement

D355-600-143

Secure the box by applying clear tape over it. Place MFSP Kit and then insert spacepod. Wrap spacepod floor in foam and place next to spacepod, then insert hardware kit and paperwork. Close box, strap three times, and apply clear tape over strappings. Apply D2729-3 label as per instructions in QSI 014.

D2729-4

D2729-3

Part No.	N/A	Q/C	CHG005
P/N	D355-600-143	S/C	SH93-88
DESC	Spacepod, LH	S/C	SR00098NY
LOT	BXXXXXX	S/C	SR00099NY
AS355			

TE APPROVAL & SIGNATURE DATE: 14/07/29

		Dart Aerospace Ltd. 1270 Aberdeen Street Hawkesbury, ON K6A 1K7 CANADA TEL.: 1 613 632-5200
SPACEPOD, LH		
P/N: D355-600-143		CHG005
B/N: BXXXXXX		

Revision: E
Date: 14.07.28